Safety

1) Keep children away from unit at all times while in operation and/or plugged in.
2) Do not put fingers or other objects in unit while in operation and/or plugged in.
3) Do not operate in pooled water to avoid electric shock.
4) Unit must be kept dry at all times, including motor, wiring and exterior. If unit becomes wet, thoroughly dry before next operation.
5) Indoor use: use only with a grounded plug and/or extension cord to avoid risk of electrical shock or fire. Remember never to use a cord with any kind of damage or wear.
6) Make sure the power source is sufficient to meet the requirements of the blower.
7) Keep air intakes clear at all times to avoid clogging or blocking in order to prevent overheating the unit. Blocking the air intakes could result in a fire or electrical hazards.
8) Do not remove any screens or safety guards from this unit to prevent injury to persons, and to avoid objects from coming in contact with the blower wheel. Unit damage in this manner will void your warranty.
9) Do not operate unit close to any dangerous areas, such as explosive gases, flammables, heaters and unventilated environments, which may result in explosions or electrical hazzards.
10) Do not use any form of speed control device as doing so may risk injury or fire.
11) Always place blower on a smooth and leveled surface for safe operation.
12) Do not operate in stacked position.
13) Do not use unit if damaged.
14) Before cleaning or servicing unplug unit.
15) All blowers in operation must be supervised at all times.
16) Do not expose to rain, water or snow.
17) Unit must be connected to a g.f.c.i.(ground fault circuit interrupter) protected receptacle.

Limited Warranty

Proof of purchase is required on all warranty claims.

1 Year Warranty:

B-Air will cover all parts (except power cord) within one year of purchase B-Air will pay repair costs and one way ups ground service shipping to your location within the 48 contiguous states. Proof of purchase is required.

Customer is responsible for shipment of damaged unit to b-air warehouse for repair. Canada and non-contiguous states must pay freight both ways.

B-Air will cover all parts (except power cord).

5 Years Warranty:

B-Air will cover housing from date of original purchase. proof of purchase is required.

Any signs of misuse including; but not limited to rough handling, abuse, tampering, improper voltage use, unauthorized maintenance and repairs are <u>NOT Covered</u> under our warranty policy.